


## Documentatie tehnica motosapa 5500R



## Producător motoutilaje

## Documentatie tehnică

Nr.crt	Denumire produs	Cod comanda
1	Dop	pslppt-01
2	Piulita	pslppt-02
3	Surub	pslppt-03
4	Ansamblu freze dr	pslppt-04
4a	Ansamblu freze	pslppt0203
5	Protectie	pslppt-05
6	Ansamblu reductor	pslppt0202
7	Surub	pslppt-07
8	Ansamblu freze st	pslppt-08
9	Aparatoare	pslppt-09
10	Surub	pslppt-10
11	Sasiu	pslppt-11
12	Fulie reductor	pslppt-12
13	Curea	pslppt-40
14	Surub	pslppt-14
15	Saiba	pslppt-15
16	Pana	pslppt-16
17	Fulie motor	pslppt-17
18	Distantier	pslppt-18
19	Sanie	pslppt-19
20	Surub	pslppt-20
21	Grower	pslppt-21
22	Saiba	pslppt-22
23	Flansa	pslppt-23
24	Piulita	pslppt-24
25	Motor	pslppt0201
26	Surub	pslppt-26
27	Maneta ambreiaj	pslppt-27
28	Cablu ambreiaj	pslppt-5
28a	Cablu ambreiaj 5500	ps550028
29	Surub	pslppt-29
30	Siguranta	pslppt-30
31	Arc	pslppt-31
32	Piulita	pslppt-32
33	Clema	pslppt-33
34	Corn st	pslppt-34
35	Maner	pslppt-35
36	Surub	pslppt-36
37	Saiba	pslppt-37
38	Brida	pslppt-38

## Producător motoutilaje

## Documentatie tehnică

39	Suport coarne	pslppt-39
40	Corn dr	pslppt-13
41	Cablu acceleratie	pslppt-41
42	Surub	pslppt-42
43	Maneta acceleratie	ps777k-6
44	Piulita	pslppt-44
45	Siguranta	pslppt-45
46	Picior adancime	pslppt-46
47	Parghie	ps550047
48	Arc	ps550048
49	Surub	pslppt-49
50	Suport roata	pslppt-50
51	Siguranta	pslppt-51
52	Arc	pslppt-52
53	Surub	pslppt-53
54	Roata	pslppt-54
55	Saiba	pslppt-55
56	Piulita	pslppt-56